

INSTALLATION INSTRUCTIONS

Code: VAL222MV / VAL228MV

The VAL222MV and VAL228MV are 2 port spring return valves with 22mm/28mm compression fittings and an auxiliary switch. This is for general purpose flow control applications or central heating systems. When correctly wired with an appropriate room thermostat, cylinder thermostat and programmer the valve will control the water from the boiler to hot water and from the boiler to central heating.

Specifications:

Supply voltage: 240V AC 50Hz

Power consumption: 6W


Operating temperature range: +5°C to +88°C

Cable length - 1 Metre

Maximum differential pressure for 22mm: 1 Bar

Maximum static pressure: 10.0 Bar
 Maximum fluid temperature: 100°C

Maximum ambient temperature: 52°C



Installation:

Before fitting the valve, read through the plumbing and wiring instructions below. When replacing the valve actuator only, set the Auto/Manual lever to the "Manual Open" position before removal. On the replacement actuator set the Auto/Manual lever to the "Manual Open" position before fitting.

Plumbing:

When connecting to pipe work do NOT use the actuator for leverage. Valves should be held by wrench flats on body. Place the AUTO/MAN lever in the MAN position when filling, venting or draining the system.



TAKE CARE NOT TO OVERTIGHTEN

Wiring:



All wiring must be carried out by a competent electrician.



All controls must be earthed. All valves should have a means of disconnection from electrical mains supply which incorporates a contact separation of at least 3mm in all Poles.

All wiring should be carried out to IEE Regulations;

Brown - Live


Orange - End switch Out

Grey - End switch In

Blue - Neutral

Green & Yellow - Earth

Typical wiring circuit using two zone valves, programmer, room thermostat and cylinder thermostat






INSTALLATION INSTRUCTIONS

Code: VAL322MP / VAL328MP

The VAL322MP and VAL328MP are 3 port spring return mid position valves with 22mm/28mm compression fittings and a 230V AC switched output. This is for use on fully pumped systems which, when correctly wired with an appropriate room thermostat, cylinder thermostat and programmer will control the hot water from the boiler to hot water to either hot water only, heating only, or both simultaneously.

Specifications:

- Supply voltage: 240V AC 50Hz
- Power consumption: 6W
- Operating temperature range: +5°C to +88°C
- Cable length 1 Metre
- · Maximum differential pressure for 22mm: 1 Bar
- Maximum static pressure: 10.0 Bar
- Maximum fluid temperature: 100°C
- Maximum ambient temperature: 52°C



Installation:

Before fitting the valve, read through the plumbing and wiring instructions below. When replacing the valve actuator only, set the Auto/Manual lever to the "Manual Open" position before removal. On the replacement actuator set the Auto/Manual lever to the "Manual Open" position before fitting.

Plumbing:

When connecting to pipe work do NOT use the actuator for leverage. Valves should be held by wrench flats on body. Place the AUTO/ MAN lever in the MAN position when filling, venting or draining the system.



TAKE CARE NOT TO OVERTIGHTEN

Wiring:



All wiring must be carried out by a competent electrician.

All controls must be earthed. All valves should have a means of disconnection from electrical mains supply which incorporates a contact separation of at least 3mm in all Poles.

All wiring should be carried out to IEE Regulations;

White - Room thermostat Call / Heating On

Grey - Cylinder thermostat satisfied / Hot water off

Orange - Cylinder thermostat Call / Boiler & Pump


Blue - Neutral


Green & Yellow - Earth


Mounting Options:

Valves may by mounted vertically, or horizontally within the limits shown in the diagram to the right

Typical wiring circuit using mid position valve, programmer, room thermostat and cylinder thermostat







TFC GROUP Tower House, Vale Rise, Tonbridge, Kent, TN9 1TB Telephone: 01732 359888 Fax: 01732 354445